



Brake Band | 6294821

Product Images

Description

Metal Brake Band for Powermatic band saws. Used with brake pedal and brake wheel to slow and stop the saw blade. Screwdriver required for replacement. Trust this authentic OEM part. See model diagram and owner's manual for installation details and precautions which should be taken. One band.

Additional Information

Stock Number

6294821