



Knob | JWBS10OS-97

Product Images



Door lock knob for JET JWBS-10 bandsaws. Made of high-quality plastic. This part is designed to attach to the handle and is used to lock the door. Sold individually. For installation steps and tools, related parts and precautions, refer to your owner's manual and model schematics.

Additional Information

Stock Number

JWBS100S-97